

Firmware Upgrade Tutorial for Move LightGo and Wireless Remote Control

Reason for This Firmware Update:

This release includes the following improvements:


- 1) Added Joystick & Angle Limit Customization for the wireless remote
- 2) Fixed known bugs to enhance system stability

Please follow the steps below to complete the update:


Step 1: Use the USB cable (USB-A to USB-C) to connect the right side of the LightGo and computer

(same step for connection between Wireless Remote Control and Computer- can use both USB-A to C and USB C to C cable in this case)

Step 2: Open falcam-tools, click "**Open**", then select "**Browse**" to choose and load the firmware file.



Step 3: Click "**Upgrade**" and wait for the progress bar to reach 100%.



Sign of Successful LightGo Upgrade:

After completing the above steps, the LightGo's indicator light will change from blue to green, indicating the firmware upgrade is complete.

**Sign of Successful Wireless Remote Control Upgrade:**

Successful update is indicated by a power cycle of the remote's display (screen turns off, then reboots automatically).

Please make sure that both LightGo and the wireless remote control are running the most recent firmware versions.

Latest Firmware Versions (as of June 20, 2025)

Move LightGo: v117

Wireless Remote: v116